



5 Channel Timer Instructions



1: SETTING UP THE MOTOR: During the settings, the interval between two operations must be less than 6 seconds to keep the motor in the programming mode.




Front



Back



1. SET CURRENT TIME




Press MODE button to switch to manual mode.

Long press TIME SETTING button for 3 seconds until the hours indicator starts to blink.

Press UP or DOWN to adjust the hours to current time.

Press P1+ until the minute indicator starts to blink.



Press UP or DOWN to adjust the WEEK day to current.

Press P1+ until the WEEK indicator starts to blink.

Press UP or DOWN to adjust the MINUTES to current time.

5 Channel Timer Instructions

1. SET CURRENT TIME (CONTINUED)



Press Time Setting button for 3 seconds. Both the HOUR and MINUTE indicator will blink.




Press TIME SETTING button again to start the seconds count from ZERO.



2. SET TIMERS





Press MODE button to switch to AUTO mode.



Long press TIME SETTING button for 3 seconds until the DAY indicator starts to blink.




Press P1+ to select the desired combination. Press STOP to confirm.




Press UP or DOWN to select the HOUR for shades to OPEN. Press P1+ to confirm.




Long press TIME SETTING button for 3 seconds until the HOUR and MINUTE indicators blink.



Press UP or DOWN to select the MINUTES for shades to CLOSE. Press P1+ to confirm.



Press UP or DOWN to select the HOUR for shades to CLOSE. Press P1+ to confirm.



Press UP or DOWN to select the MINUTES for shades to OPEN. Press P1+ to confirm.